

Drawer setting

Drawer setting: abbreviations


Chest of drawers

SP = Thickness of the drawer

LN = Nominal runner length

PM = Depth of the cabinet


X = Internal width of the cabinet



Drawer dimensions

LC = Runner length - 10 mm

X - 41 = Internal width of the drawer



The drawer length is 10 mm shorter than the runner length

The internal width of the drawer is 41 mm less than the internal width of the cabinet